

Ultraclean PH Technical Data Sheet



Description

Ultrawave's Ultraclean PH is an acid solution that is used for metal rebrightening, removal of rust & anti-rust treatment. Also used as a descaler.

Applications

Suitable for metal rebrightening (removes oxide layer), removal of rust & anti-rust treatment. Also used as a descaler for removal of limescale. Not suitable for aluminium.

Directions for Use

Dilute with water to give a 2% to 5% (20mL to 50mL per Litre) solution before use with water. Ensure thorough mixing of the solutions. Do not mix with other solutions.

The required dosage will depend on your cleaning application and the level of contamination. Items should be rinsed with water and dried immediately after processing. Please refer to the product safety data sheet before use. Use only as directed.

Technical Data

These figures are typical and should not be interpreted as specifications, refer to the product safety data sheet for details

Characteristic	Value/Description
Appearance	Colourless
Odour	Acrid
pH (@ 1%)	<2

Supplied as 6 x 1Litre Bottles (SKU: F50021) or as 25L Drum (SKU: F00020).

Disposal

Dispose of waste to licensed waste disposal site in accordance with the requirements of the local Waste Disposal Authority.

Storage

Store in a cool, dry place protected from frost and away from strong alkalis. Store upright in original containers. Shelf-life up to 12months when stored in a cool, dark environment.

Specifications are subject to change for continual improvements